

IntelliZone® Proximity Detection



- For all section equipment and light-duty vehicles
- Proven in U.S. coal mines
- Robust & compact locators
- Precise worker location & dynamic zones

The Matrix IntelliZone[®] proximity detection system allows users to create customized Caution, Shutdown and Operator Zones around all mobile equipment. IntelliZone technology detects workers in low-visibility or obscured line-of-sight locations while allowing the operator to work in a safer location.

All components of the Matrix IntelliZone system are extremely durable, simple to operate and easy to maintain.



Phone: 812.490.1525 • Fax: 812.490.1582 • 3299 Tower Drive • Newburgh, Indiana 47630 • email: sales@matrixteam.com



 SharpZone[™] technology minimizes false alarms and allows long-range, through-curtain detection
Shaped zones allow precise location of support workers without reducing production

The Matrix IntelliZone[®] proximity detection system helps train personnel to stay clear of danger zones present around mobile equipment. The system is designed for use on all brands of continuous miners, shuttle cars and other mobile underground equipment or vehicles.

Proven Technology in U.S. Coal Mines – first installed in 2009, more than 90% of all US underground coal mines operating with proximity detection systems use Matrix technology.

CONTINUOUS MINER / SHUTTLE CAR

- Highly Reliable machine-integrated "Drivers" are compact and robust for maximum uptime and manufactured for harsh operating conditions.
- Service & Support all Matrix IntelliZone systems are backed by Matrix's outstanding field service technicians and distribution network.
- Data Logging IntelliZone is the only MSHA-approved prox system that allows precise personnel location and data logging.

DRIVER

The MOST ADVANCED proximity detection system operating worldwide in underground mines

DRIVER

MSHA Approved



Locator

The IntelliZone Locator uses audible and visual alerts to warn personnel of potential danger.

The Locator is compact, lightweight, simple to use and powered by a rechargeable battery.

All IntelliZone Locators for underground coal mines are Intrinsically Safe (IS).

SHUTDOWN ZONE

Immediately disables movement of equipment when locator detected in this zone.

Constant tone warning and flashing red light on driver & locator.

Operation resumes when locator leaves zone.

CM OPERATOR ZONE

Created by Matrix SharpZone technology when shuttle car is loading.

Allows operator to stand or kneel in a safe position without triggering the Caution Zone warning.

CAUTION ZONE

Beeping tone warning and flashing yellow light on locator.


Flashing yellow light on driver.

SharpZone™ Technology for Precise Programmable Awareness Zones

Intellizone[®] PROXIMITY DETECTION

Matrix's leading-edge SharpZone technology creates equipment-specific straight line and angled safety areas for the most effective Caution and Shutdown zones. These zones help protect miners from mobile equipment injuries and minimize nuisance warnings or shutdown. For example:

- Mobile haulage awareness zones vary based on speed and direction of travel. Higher speed means longer forward zones to allow for higher stoppage time.
- Mobile haulage awareness zones can "see" through curtains to help avoid worker collisions.
- Zones around CM tail automatically shrink in cutting mode and expand while tramming.
- Customized "green" zones can be generated within the awareness zones to allow operators to stand, kneel or, if appropriate, ride in safe locations without setting off a zone alert.




MOBILE HAULAGE

DRIVERS

Zones Extend as Speed Increases

As shuttle car speed increases, the zones increase in length to accommodate the longer required stopping time.

The zones can "see" through barrier curtains, which helps protect workers.



OPERATOR ZONE

Matrix SharpZone technology creates an in-cab "green" zone so operator does not trigger alarms while driving mobile equipment.

SHUTDOWN ZONE

Auto-stops when worker detected in Shutdown Zone.

Audible warning and flashing Red light on driver & locator.

Operator receives in-cab warning. Operation resumes when worker exits zones.

CAUTION ZONE

Auto-slows speed when worker detected in Caution Zone.

Audible warning and flashing Yellow light on driver & locator.

Operator receives in-cab warning (optional).



Matrix IntelliZone® Warning System Summary



Worker Location	Locator	Driver		Continuous Miner	Mobile Haulage
Outside Zones	Flashing Green Light	Green Light	-	Normal Operation	Normal Operation
Caution Zone	Flashing Yellow Light & Beeping Tone	Flashing Yellow Light		Normal Operation	Speed Auto-Slow
Shutdown Zone	Flashing Red Light & Fast-Beep Tone	Flashing Red Light		Auto-Stop	Auto-Stop

IntelliZone Locator Charging Station



Joy SMARTZONE Compatible



GLOBAL APPROVALS

- MSHA
- SANS 60079-0/1/11/18
- IECEx

NOTICE

Matrix IntelliZone is intended to help teach mine personnel to safely interact with equipment and stay clear of danger zones. It is not intended to replace safe operating practices. IntelliZone is a useful tool to assist in personnel training.



Information and specifications contained in this document are subject to change without notice.

IntelliZone and SharpZone are registered trademarks of Matrix Design Group, LLC.

Phone: 812.490.1525 • Fax: 812.490.1582 • 3299 Tower Drive • Newburgh, Indiana 47630 • email: sales@matrixteam.com